



# Properties of standard Bal Spring® canted coil spring materials

Technical Report  
TR-9 (Rev. Q; 10-19-17)  
(100-44)

19650 Pauling  
Foothill Ranch, CA  
USA 92610-2610  
t +1 949 460 2100  
f +1 949 460 2300

Jollemanhof 16, 5th floor  
1019 GW Amsterdam  
The Netherlands  
t +31 20 638 6523  
f +31 20 625 6018

Suite 901, Chinachem  
Century Tower  
178 Gloucester Road,  
Wanchai, Hong Kong  
t +852 28681860  
f +852 22956753

[www.balseal.com](http://www.balseal.com)



## Contents

1.0	Summary	3
2.0	Types of Spring Materials	3
2.1	BSE1 or BSE2 (Stainless Steel)	3
2.2	BSE3 or BSE4 (Stainless Steel)	3
2.3	BSE5 (Stainless Steel)	3
2.4	BSE6 (Stainless Steel)	3
2.5	BSE9 (Beryllium Copper Alloy)	3
2.6	BSE11 (Zirconium Chromium Copper Alloy)	3
2.7	BSE12 (Copper Alloy)	4
2.8	BSE17 (Nickel Alloy)	4
2.9	BSE18 (Nickel Alloy)	4
2.10	BSE19 (Cobalt Nickel Alloy)	4
2.11	BSE22 (Platinum Iridium Alloy)	4
2.12	BSE26 (Titanium Alloy)	4
2.13	BSE29 (Copper Alloy)	4
2.14	BSE30 (Very High Conductivity Copper Alloy)	4
3.0	Advantages, Limitations, and Typical Applications of Spring Materials	5
4.0	Physical, Electrical, and Mechanical Properties of Spring Materials at Normal and After Elevated Temperatures	6
4.1	Physical and Mechanical Properties at 70°F (21°C)	6
5.0	Chemical Compatibility of Standard Bal Spring® Materials	8

The information, descriptions, recommendations and opinions set forth herein are offered solely for your consideration, inquiry, and verification and are not, in part or in whole, to be construed as constituting a warranty, expressed or implied, nor shall they form or be a part of the basis of any bargain with Bal Seal Engineering, Inc. If any sample or model was shown to or provided by Buyer/User, such sample or model was used merely to illustrate the general description and type of goods. Such use is not to be construed as a warranty that the goods will conform to the sample or model. Furthermore, THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ALL OTHER WARRANTIES, IMPLIED OR EXPRESSED, ARE EXCLUDED AND SHALL NOT APPLY. This document provides product options for further investigation by Buyers/Users having technical expertise. The Buyer/User, through its own analysis and testing, is solely responsible for making the final selection of the products and for assuming that all performance, safety and warning requirements for the application are met. It is recommended that Buyers/Users run evaluation testing under actual service conditions to determine whether proposed Bal Seal Engineering products are suitable for the intended purpose. Nothing contained herein or in any of our literature shall be considered a license or recommendation for any use that may infringe patent rights. (LE-17)

## 1.0 Summary

Various types of canted coil spring materials are available from Bal Seal Engineering, Inc. Material selection depends primarily on the medium and operating temperature of the application.

This report describes physical, mechanical and chemical resistance properties of these materials at normal temperatures and after cooling from elevated temperatures.

## 2.0 Types of Spring Materials:

The following are standard and special spring materials available from Bal Seal Engineering, Inc. Mechanical properties are affected by temperature, diameter of wire, and degree of cold working. Typical physical properties at 70 °F (21 °C) are shown in Table 2.

### 2.1 BSE1 or BSE2 (Stainless Steel)

BSE1 or BSE2 is a chromium-nickel stainless steel. It can operate at temperatures  $-330$  °F to  $+570$  °F ( $-200$  °C to  $+300$  °C).

### 2.2 BSE3 or BSE4 (Stainless Steel)

BSE3 or BSE4 has a higher nickel content, which provides better corrosion resistance than BSE1 or BSE2. The suggested temperature range is  $-330$  °F to  $+570$  °F ( $-200$  °C to  $+300$  °C).

### 2.3 BSE5 (Stainless Steel)

This material has a lower carbon content than BSE3 or BSE4. The temperature range is  $-330$  °F to  $+570$  °F ( $-200$  °C to  $+300$  °C), with mechanical properties similar to BSE3 or BSE4.

### 2.4 BSE6 (Stainless Steel)

This material has the same composition as BSE5 except that it is melted in vacuum to reduce impurities.

### 2.5 BSE9 (Beryllium Copper Alloy)

This is a high-strength copper alloy. The operating temperature range is  $-420$  °F to  $+250$  °F ( $-250$  °C to  $+175$  °C).

### 2.6 BSE11 (Zirconium Chromium Copper Alloy)

This copper alloy has lower yield strength than BSE9, yet still exhibits excellent electrical conductivity. The maximum operating temperature is  $392$  °F ( $200$  °C).

### 2.7 BSE12 (Copper Alloy)

This copper alloy has lower strength than BSE9, yet still exhibits excellent electrical conductivity. The maximum operating temperature is 392 °F (200 °C).

### 2.8 BSE17 (Nickel Alloy)

BSE17 is a nickel-based alloy that has higher corrosion resistance than BSE1 or BSE2, BSE3, or BSE4, and BSE5 stainless steel with a higher percentage of nickel. Operating temperature range is from -330 °F to +750 °F (-200 °C to +400 °C).

### 2.9 BSE18 (Nickel Alloy)

BSE18 offers the highest corrosion resistance of the standard spring materials. Its temperature range is -70 °F to 1250 °F (-60 °C to +677 °C).

### 2.10 BSE19 (Cobalt Nickel Alloy)

BSE19 is a nickel alloy used in corrosive environments and long service life applications. It maintains high mechanical properties and has a temperature range from -70 °F to +550 °F (-60 °C to +288 °C). This material is a noncorrosive metal and will cause galvanic corrosion when coupled with carbon steel, or BSE3 or BSE4, and thus is not recommended for use under such conditions.

### 2.11 BSE22 (Platinum Iridium Alloy)

This material has limited use as a spring and is considered a specialty material.

### 2.12 BSE26 (Titanium Alloy)

BSE26 has a temperature range of -300 °F to +600 °F (-200 °C to +315 °C). This material has higher corrosion resistance than BSE1 or BSE2 and BSE3 or BSE4 stainless steels, BSE17, and BSE18. The low mechanical properties can lead to deformation under relatively low compression forces of the material.

### 2.13 BSE29 (Copper Alloy)

This high-strength copper alloy has twice the conductivity as BSE9 with the advantage that it does not contain beryllium. The maximum operating temperature is 392 °F (200 °C).

### 2.14 BSE30 (Very High Conductivity Copper Alloy)

This material has higher conductivity than BSE11 and BSE12. It has slightly lower mechanical properties than BSE11 but slightly higher than BSE12. The maximum operating temperature is 392 °F (200 °C).

### 3.0 Advantages and Limitations of Spring Materials

Table 1: Advantages and limitations of standard Bal Spring® materials

Material	Advantages	Limitations	Typical Applications
<b>BSE1 or BSE2 (Stainless Steel)</b>	<ul style="list-style-type: none"> <li>• Low cost and readily available</li> <li>• Highest tensile strength of all standard Bal Spring materials</li> </ul>	<ul style="list-style-type: none"> <li>• Lower corrosion resistance than BSE3 or BSE4 and BSE5</li> <li>• Mechanical properties change at elevated temperatures</li> </ul>	<ul style="list-style-type: none"> <li>• General service</li> </ul>
<b>BSE3 or BSE4 (Stainless Steel)</b>	<ul style="list-style-type: none"> <li>• Better corrosion resistance than BSE1 or BSE2 due to higher nickel and molybdenum content</li> </ul>	<ul style="list-style-type: none"> <li>• Mechanical properties lower than BSE1 or BSE2</li> </ul>	<ul style="list-style-type: none"> <li>• Food processing</li> </ul>
<b>BSE5 (Stainless Steel)</b>	<ul style="list-style-type: none"> <li>• Higher corrosion resistance than BSE3 or BSE4 due to lower carbon content</li> </ul>	<ul style="list-style-type: none"> <li>• Higher cost than BSE3 or BSE4</li> </ul>	<ul style="list-style-type: none"> <li>• Biomedical</li> <li>• Corrosive environments</li> <li>• Laboratory</li> <li>• Food processing</li> </ul>
<b>BSE6 (Stainless Steel)</b>	<ul style="list-style-type: none"> <li>• Very low impurities</li> </ul>	<ul style="list-style-type: none"> <li>• Limited availability</li> <li>• Higher cost than BSE5</li> </ul>	<ul style="list-style-type: none"> <li>• Body implants</li> </ul>
<b>BSE9 (Beryllium Copper Alloy)</b>	<ul style="list-style-type: none"> <li>• High-strength copper alloy</li> </ul>	<ul style="list-style-type: none"> <li>• Limited temperature range</li> </ul>	<ul style="list-style-type: none"> <li>• Parts requiring good electrical conductivity</li> <li>• EMI shielding</li> <li>• Electronics</li> </ul>
<b>BSE11 (Zirconium Chromium Copper Alloy)</b>	<ul style="list-style-type: none"> <li>• Excellent electrical conductivity</li> <li>• Lower cost than BSE9</li> </ul>	<ul style="list-style-type: none"> <li>• Lower strength than BSE9</li> </ul>	<ul style="list-style-type: none"> <li>• High-current applications</li> </ul>
<b>BSE12 (Copper Alloy)</b>	<ul style="list-style-type: none"> <li>• Excellent electrical conductivity</li> </ul>	<ul style="list-style-type: none"> <li>• Lower strength than BSE9 or BSE11</li> </ul>	<ul style="list-style-type: none"> <li>• High-current applications</li> </ul>
<b>BSE17 (Nickel Alloy)</b>	<ul style="list-style-type: none"> <li>• Higher corrosion resistance and operating temperature than BSE1 or BSE2, BSE3 or BSE4, and BSE5 stainless steels</li> </ul>	<ul style="list-style-type: none"> <li>• Limited availability</li> </ul>	<ul style="list-style-type: none"> <li>• Corrosive environments</li> </ul>
<b>BSE18 (Nickel Alloy)</b>	<ul style="list-style-type: none"> <li>• High resistance to stress cracking</li> <li>• High corrosion resistance</li> <li>• Resistant to cracking under NACE Level VII conditions</li> <li>• Compatible with hydrogen sulfide</li> </ul>	<ul style="list-style-type: none"> <li>• Wire size</li> </ul>	<ul style="list-style-type: none"> <li>• Petrochemical applications with hydrogen sulfide sour gas per NACE report MR-01-75</li> </ul>

Table 1 continued on page 6

### 3.0 Advantages and Limitations of Spring Materials

Table 1: Advantages and limitations of standard Bal Spring® materials continued from page 5

Material	Advantages	Limitations	Typical Applications
<b>BSE19</b> (Cobalt Nickel Alloy)	<ul style="list-style-type: none"> <li>Compatible with hydrogen sulfide</li> <li>Nickel-based material with higher modulus of elasticity than all other stainless steel materials with higher mechanical properties than other stainless steel materials</li> </ul>	<ul style="list-style-type: none"> <li>Galvanic corrosion can occur when coupled with dissimilar metals</li> </ul>	<ul style="list-style-type: none"> <li>Body implant applications such as pacemakers</li> <li>Petrochemical applications where corrosion resistance to hydrogen sulfide is necessary</li> </ul>
<b>BSE22</b> (Platinum Iridium Alloy)	<ul style="list-style-type: none"> <li>Excellent corrosion resistance</li> </ul>	<ul style="list-style-type: none"> <li>Highest cost of all spring materials.</li> <li>Increased weight loss in oxidizing atmospheres</li> </ul>	<ul style="list-style-type: none"> <li>Medical electronics</li> </ul>
<b>BSE26</b> (Titanium Alloy)	<ul style="list-style-type: none"> <li>Compatible with biomedical fluids like proteins, peptides, and enzymes</li> <li>Contains no chrome or nickel to affect these molecules</li> </ul>	<ul style="list-style-type: none"> <li>Low tensile strength</li> <li>Very high cost</li> </ul>	<ul style="list-style-type: none"> <li>Certain biomedical applications such as those in which contact with fuming nitric acid is required</li> </ul>
<b>BSE29</b> (Copper Alloy)	<ul style="list-style-type: none"> <li>Good electrical conductivity and high-strength copper alloy</li> </ul>	<ul style="list-style-type: none"> <li>Lower conductivity than BSE9, BSE11, and BSE30</li> </ul>	<ul style="list-style-type: none"> <li>General service</li> </ul>

## 4.0 Physical, Electrical, and Mechanical Properties of Spring Materials at Normal and After Elevated Temperatures

### 4.1 Physical and mechanical properties at 70 °F (21 °C)

Table 2 outlines ranges of physical, electrical, and mechanical properties of standard Bal Spring® wire materials based on a wide range of wire sizes included in each purchasing specification. Tensile modulus and yield strength are reference values.

Table 2: Physical, electrical, and mechanical properties of standard Bal Spring® wire materials

Material	Min & Max Temp. Range °F (°C)	Density (Specific Gravity) lb/in <sup>3</sup> (gm/cc)	Electrical Resistivity μΩ-in (μΩ-cm)	Electrical Conductivity* %IACS	Ultimate Tensile Strength ksi (MPa)	Elongation at Break %	Tensile Modulus (Reference) lb/in <sup>2</sup> (GPa)	Yield Strength (Reference) ksi (MPa)
<b>BSE1 or BSE2 (Stainless Steel)</b>	-459 °F to 570 °F (-273 °C to 300 °C)	0.290 (8.03)	28.3 at 70 °F (72.0 at 21 °C)	3%	272–355 (1875–2450)	1.9–3.2	28 x 10 <sup>6</sup> (193)	245 (1690)
<b>BSE3 or BSE4 (Stainless Steel)</b>	-459 °F to 570 °F (-273 °C to 300 °C)	0.290 (8.03)	29.1 at 70 °F (74.0 at 21 °C)	2.9%	215–275 (1482–1896)	1.9–3.2	28 x 10 <sup>6</sup> (193)	218 (1503)
<b>BSE5 (Stainless Steel)</b>	-459 °F to 570 °F (-273 °C to 300 °C)	0.290 (8.03)	29.1 at 70 °F (74.0 at 21 °C)	2.9%	153–210 (1054–1448)	1.9–5.5	28 x 10 <sup>6</sup> (193)	166 (1145)
<b>BSE6 (Stainless Steel)</b>	-459 °F to 570 °F (-273 °C to 300 °C)	0.290 (8.03)	29.1 at 70 °F (74.0 at 21 °C)	2.9%	153–210 (1054–1448)	1.9–3.2	28 x 10 <sup>6</sup> (193)	166 (1145)
<b>BSE9 (Beryllium Copper Alloy)</b>	-459 °F to 351 °F (-273 °C to 177 °C)	0.29 (8.03)	4.21 at 70°F (10.7 at 21 °C)	18%	110–135 (758–930)	1.5–3.5	18.5 x 10 <sup>6</sup> (128)	115 (792)
<b>BSE11 (Zirconium Chromium Copper Alloy)</b>	-459 °F to 392 °F (-273 °C to 200 °C)	0.321 (8.89)	0.862 at 70 °F (2.19 at 21 °C)	78%	95–115 (648–793)	1.5–3.5	17 x 10 <sup>6</sup> (117)	90 (620)
<b>BSE12 (Copper Alloy)</b>	-459 °F to 392 °F (-273 °C to 200 °C)	0.322 (8.91)	0.862 at 70 °F (2.19 at 21 °C)	78%	85–100 (586–689)	1.5–3.5	18.5 x 10 <sup>6</sup> (128)	85 (586)
<b>BSE17 (Nickel Alloy)</b>	-459 °F to 1000 °F (-273 °C to 538 °C)	0.321 (8.89)	51.2 at 75 °F (130.0 at 24 °C)	1.4%	206–272 (1420–1875)	1.5–5.7	29.7 x 10 <sup>6</sup> (205)	220 (1517)
<b>BSE18 (Nickel Alloy)</b>	-459 °F to 1202 °F (-273 °C to 650 °C)	0.299 (8.28)	48.0 at 122 °F (122.0 at 50 °C)	1.6%	190 min (1310 min)	1.7–4.0	31 x 10 <sup>6</sup> (214)	195 (1345)
<b>BSE19 (Cobalt Nickel Alloy)</b>	-459 °F to 550 °F (-273 °C to 288 °C)	0.304 (8.43)	40.7 at 70 °F (103.3 at 21 °C)	1.8%	240 to 305 (1655–2103)	1.5–2.6	34.1 x 10 <sup>6</sup> (235)	240 (1655)
<b>BSE22 (Platinum Iridium Alloy)</b>	-459 °F to 842 °F (-273 °C to 450 °C)	0.7807 (21.6)	12.2 at 70°F (31 at 21 °C)	5.60%	246–276 (1696–1903)	1.5 min	37 x 10 <sup>6</sup> (255)	195 (1345)
<b>BSE26 (Titanium Alloy)</b>	-459 °F to 572 °F (-273 °C to 300 °C)	0.163 (4.51)	19.6 at 70°F (49.8 at 21 °C)	3.4%	110–150 (758–1034)	1.5–2.6	15.2 x 10 <sup>6</sup> (105)	108 (745)
<b>BSE29 (Copper Alloy)</b>	-459 °F to 356 °F (-273 °C to 180 °C)	0.318 (8.80)	1.69 at 70 °F (4.3 at 21 °C)	40%	110–130 (724–896)	1.5–4.5	19 x 10 <sup>6</sup> (131)	110 (758)

\* Conductivity values are percentages of standard alloy conductivity.

## 5.0 Chemical Compatibility of Standard Bal Spring® Materials

The following data describes general compatibility values. It is recommended that appropriate testing be done to verify such values.

### Acids

Type	BSE1 or BSE2 (Stainless Steel)	BSE3 or BSE4, BSE5, BSE6 (Stainless Steel)	BSE17 (Nickel Alloy)	BSE18 (Nickel Alloy)	BSE19 (Cobalt Nickel Alloy)	BSE26 (Titanium Alloy)
<b>Acetic Acid</b>	A	A	A	INA	A	A
<b>Benzoic Acid</b>	A	A	A	INA	INA	INA
<b>Boric Acid</b>	A	A	A	INA	INA	A
<b>Chlorosulphonic Acid</b>	NR	NR	A	INA	INA	NR
<b>Chromic Acid</b>	NR	NR	NR	INA	INA	A
<b>Citric Acid</b>	A	A	A	INA	INA	A
<b>Formic Acid</b>	A	A	A	INA	A	INA
<b>Hydrofluoric Acid</b>	NR	NR	A	INA	INA	NR
<b>Hydrochloric Acid</b>	NR	NR	A	NR	NR	INA
<b>Nitric Acid 10%</b>	A	A	A	NR	A	A
<b>Nitric Acid 100%</b>	A	A	NR	NR	A	A
<b>Phosphoric Acid</b>	A	A	A	A	A	INA
<b>Sulfuric Acid</b>	A	A	A	A	A	INA
<b>Tartaric Acid</b>	A	A	A	INA	INA	INA

A= Acceptable    NR= Not recommended    INA= Information not available



## Alcohols

Type	BSE1 or BSE2 (Stainless Steel)	BSE3 or BSE4, BSE5, BSE6 (Stainless Steel)	BSE17 (Nickel Alloy)	BSE18 (Nickel Alloy)	BSE19 (Cobalt Nickel Alloy)	BSE26 (Titanium Alloy)
<b>Butyl Alcohol</b>	A	A	A	INA	A	INA
<b>Ethanol, Anhydrous</b>	A	A	A	INA	A	A
<b>Isopropyl Alcohol</b>	A	A	A	INA	A	A
<b>Methanol</b>	A	A	A	INA	A	INA
<b>Propanol</b>	A	A	A	INA	A	INA

## Aqueous Solutions

Type	BSE1 or BSE2 (Stainless Steel)	BSE3 or BSE4, BSE5, BSE6 (Stainless Steel)	BSE17 (Nickel Alloy)	BSE18 (Nickel Alloy)	BSE19 (Cobalt Nickel Alloy)	BSE26 (Titanium Alloy)
<b>Beer</b>	A	A	A	INA	INA	INA
<b>Chloride Salts</b>	A	A	A	INA	A	A
<b>Chlorinated Water</b>	NR	A	A	INA	INA	A
<b>Sea Water</b>	A	A	A	A	A	A
<b>Tap Water</b>	A	A	A	A	A	A

A= Acceptable    NR= Not recommended    INA= Information not available

## Fluorocarbon Solvents

Type	BSE1 or BSE2 (Stainless Steel)	BSE3 or BSE4, BSE5, BSE6 (Stainless Steel)	BSE17 (Nickel Alloy)	BSE18 (Nickel Alloy)	BSE19 (Cobalt Nickel Alloy)	BSE26 (Titanium Alloy)
<b>Freon F-12</b>	A	A	INA	INA	INA	INA
<b>Carbon Tetrachloride</b>	A	A	A	INA	INA	A
<b>Chlorine Gas</b>	A	A	A	INA	INA	INA
<b>Chlorobenzene</b>	A	A	A	INA	INA	INA
<b>Chloroform</b>	A	A	A	INA	INA	A
<b>Ethylene Glycol</b>	A	A	A	INA	INA	INA
<b>Methylene Chloride</b>	A	A	A	INA	INA	INA
<b>Sodium Chloride</b>	A	A	A	INA	A	A
<b>Sodium Chromate</b>	A	A	INA	INA	INA	INA
<b>Sodium Hydrochloride</b>	A	A	A	INA	INA	INA
<b>Trichloroethylene</b>	A	A	A	INA	INA	INA

A= Acceptable    NR= Not recommended    INA= Information not available

## Petroleum-Based Liquids

Type	BSE1 or BSE2 (Stainless Steel)	BSE3 or BSE4, BSE5, BSE6 (Stainless Steel)	BSE17 (Nickel Alloy)	BSE18 (Nickel Alloy)	BSE19 (Cobalt Nickel Alloy)	BSE26 (Titanium Alloy)
Acetone	A	A	A	INA	A	INA
Acetonitrile	A	A	A	INA	A	INA
Benzene	A	A	A	INA	INA	A
Gasoline	A	A	A	INA	INA	INA
Jet Fuel	A	A	A	INA	INA	A
Kerosene	A	A	A	INA	INA	A
Methyl Ethyl-Ketone	A	A	INA	INA	INA	INA
Mineral Oil	A	A	A	INA	INA	INA
Naphtha	A	A	A	INA	INA	INA
N-Hexane	A	A	A	INA	INA	INA
Oleum	A	A	A	INA	INA	INA
Stoddard Solvent	A	A	NR	INA	INA	INA
Toluene	A	A	A	INA	INA	INA
Xylene	A	A	A	INA	INA	INA

A= Acceptable    NR= Not recommended    INA= Information not available

## Biomedical

Type	BSE1 or BSE2 (Stainless Steel)	BSE3 or BSE4, BSE5, BSE6 (Stainless Steel)	BSE17 (Nickel Alloy)	BSE18 (Nickel Alloy)	BSE19 (Cobalt Nickel Alloy)	BSE26 (Titanium Alloy)
Proteins	INA	INA	INA	INA	INA	A
Peptides	INA	INA	INA	INA	INA	A
Enzymes	INA	INA	INA	INA	INA	A
Monoclonal Antibodies	INA	INA	INA	INA	INA	A
Synthetic Oligo-Nucleotides	INA	INA	INA	INA	INA	A
Implant Applications	INA	INA	INA	INA	INA	A

## Miscellaneous

Type	BSE1 or BSE2 (Stainless Steel)	BSE3 or BSE4, BSE5, BSE6 (Stainless Steel)	BSE17 (Nickel Alloy)	BSE18 (Nickel Alloy)	BSE19 (Cobalt Nickel Alloy)	BSE26 (Titanium Alloy)
Ammonia	A	A	A	INA	INA	A
Ammonium Hydroxide	A	A	A	INA	INA	A
Bromine Gas	NR	NR	A	INA	INA	INA
Carbon Dioxide	A	A	A	INA	INA	A
Fluorine Gas	NR	NR	NR	INA	INA	INA
Hydrogen	A	A	A	INA	A	A
Hydrogen Sulfide	A	A	A	A	A	INA
Nitrogen	A	A	NR	INA	INA	A
Oxygen	NR	NR	A	A	A	NR

A= Acceptable    NR= Not recommended    INA= Information not available